

GUARDE ESTAS INSTRUCCIONES

- 1) 1) Para desconectarlo, coloque todos los controles en la posición de apagado OFF, luego desenchufe el aparato.
- 10) Nunca deje caer ni inserte un objeto en ninguna de las aberturas. Puedan obstruir las entradas de aire.
- 9) Nunca opere el aparato en una superficie blanda, como un sofá o una cama, donde se pelusas, cables y elementos similares.
- 8) Nunca opere este aparato con las entradas de aire bloqueadas. Manténgalas libres de
- 7) Mantenga el cable alejado de las superficies calientes.
- 6) No coja el aparato por el cable, ni use el cable como agarre.
- 5) a un Centro de Servicio autorizado para que lo inspeccionen y lo reparen. correctamente, si ha caído, si está dañado o si ha caído en el agua. Llévelo o mandelo
- 4) Use este aparato solamente con el propósito para el cual fue diseñado y según se describe en este manual. Solo use accesorios recomendados por el fabricante.
- 3) No use este aparato debajo de una cobija o de una almohada. Esto podría provocar un recalentamiento del motor y presentar un riesgo de incendio, electrocución o herida.
- 2) Este aparato no debería ser utilizado por, sobre o cerca de niños o personas con alguna discapacidad.
- 1) Nunca deje este aparato desatendido mientras está conectado. Desconéctelo cuando no esté en uso.

ADVERTENCIA–Para reducir el riesgo de quemaduras, electrocución, incendio o herida:

- 4) No deje o guarde este aparato donde pueda caer o ser jalado a la tina o al lavabo. No lo coloque o lo deje caer al agua u otro líquido.
- 3) No use este aparato mientras usted se está bañando o tomando una ducha.
- 2) No trate de alcanzar el aparato si cae al agua. Desconéctelo inmediatamente.
- 1) Siempre desconecte este aparato después de usarlo y antes de limpiarlo.

PELIGRO–Para reducir el riesgo de muerte o heridas por electrocución:

Al usar aparatos eléctricos, siempre se deben tomar precauciones básicas, entre las cuales las siguientes. Lea todas las instrucciones antes de usar este aparato.

IMPORTANTES MEDIDAS DE SEGURIDAD

HOW TO OPERATE THE CONAIR® SOUND THERAPY RELAXATION SYSTEM

- 1) Plug the pin end of the adapter into the DC jack on the side of the Conair® Sound Therapy Relaxation System. Insert the plug end of the adapter into any 120V AC household outlet OR insert four AA batteries (not included) as shown inside the battery compartment, on the bottom of the sound system. LED will light to show power ON.
- 2) Press the ON/OFF button once to turn on the sound system. The sound system will generate the natural sound selected the last time the system was used.
- 3) Choose one of ten natural sounds by pressing the corresponding button once.
- 4) To turn off the Conair® Sound Therapy Relaxation System, press and release the ON/ OFF button again. The sound that was last selected will be remembered and it will be reproduced automatically the next time your sound system is turned on.
- 5) To adjust the speaker volume, turn the volume control located at the front of the sound system.
- 6) To activate the 60-minute timer when the sound system is on, slide the 60-MINUTE AUTO TIMER switch to ON. The sound system will automatically shut off after 60 minutes. If the timer switch is activated again while operating, the timer will reset itself to another 60 minutes.
- 7) If the 60-MINUTE AUTO TIMER switch is turned to OFF, the Conair® Sound Therapy Relaxation System will remain on until you turn it off. To turn the sound system off, press the ON/OFF button once.

- 6) Funciona con cuatro baterías de tipo AA (no se incluyen) o con adaptador de C.A. (proveído)
- 5) Control de volumen
- 4) Botón de encendido/apagado
- 3) Apagado automático después de 60 minutos (opcional)
- 2) Parante ancho de tres pulgadas que reproduce sonidos efectivos.
- Tormenta (THUNDERSTORM): Permite que el estruendo de la tormenta le arrulle.
- Pájaros cantores (SONGBIRDS): Despierte al canto armonioso de las aves.
- Bosque tropical (TROPICAL FOREST): Viaje en la profundidad de la selva tropical.
- Latido del corazón (HEARTBEAT): Calme a los bebés con la quietud rítmica del latido del corazón.
- Riachuelo (RUNNING STREAM): Apacigüe su alma con la serenidad del agua corriente.
- Ruido blanco (WHITE NOISE): Estática enfundada que neutraliza el ruido no deseado.
- Cascada (WATERFALL): Refrescante sonido de cataratas. Ideal para trabajar.
- Océano (OCEAN WAVES): Alivie las tensiones con el efecto calmante de las olas.
- Lluvia (RAINFALL): Tranquillice su mente con el tamborileo de la lluvia.
- Noche de verano (SUMMER NIGHT): Relájese escuchando el murmullo de la noche caliente.
- 1) 10 sonidos grabados digitalmente, con excepcional claridad:

CARACTERÍSTICAS

Gracias por escoger el reproductor de sonidos naturales de Conair®. Este sistema genera sonidos naturales que le ayudarán a relajarse o neutralizar el ruido no deseado, para crear un ambiente propicio a la relajación o al trabajo, en su casa, en su oficina o en cualquier lugar. Para disfrutar plenamente de su aparato, siempre lea las instrucciones cuidadosamente antes de usarlo. Para su comodidad, su aparato puede funcionar con baterías (no se incluyen) o con el adaptador proveído.

OPERACIÓN

Esta unidad está equipada con un adaptador de 6V/250mA C.D., aprobado por UL. Para más información, favor de comunicarse con el servicio postventa de Conair.

ADAPTADOR DE C.A.

TO INSERT BATTERIES

- 1) Unlatch and lift off the battery compartment door (located on the bottom of the sound system).
- 2) Insert four AA 1.5 volt alkaline batteries, as shown inside the battery compartment.
- 3) Replace the battery compartment door and return the sound system to its upright position.

Please note

If you will be running the Conair® Sound Therapy Relaxation System for a long period of time, it is recommended that you use the adapter. This will preserve the life of the batteries. Battery power is not consumed when the adapter is used.

If you plan to run the sound system while drifting off to sleep, it is suggested that you use the 60-minute timer, located on the side of the sound system, to automatically shut off the sound system. This will preserve the battery life.

To prevent the sound system from turning on accidentally while you are travelling, remove the batteries before packing. The sound system will run solely on the adapter if the batteries are not used.

Batteries are a good backup in case of power failure.

Dispose of batteries in a proper manner appropriate to your provincial, state and local regulations.

Be sure to remove batteries when storing your Conair® Sound Therapy Relaxation System. The batteries will drain if they are left connected when the sound system is unplugged. Old batteries may leak chemicals that can badly damage the sound system.

CÓMO INSTALAR LAS BATERÍAS

OPERATING INSTRUCTIONS

Congratulations on your purchase of the Conair® Sound Therapy Relaxation System. This system provides soothing sounds to relax you and to mask unwanted noise. The Conair® Sound Therapy Relaxation System allows you to create a soothing environment at home, at the office or anywhere you would like to relax. Used as directed, the Conair® Sound Therapy Relaxation System will provide you with dependable service.The Conair® Sound Therapy Relaxation System can be used with a cord by inserting the pin end of the adapter into the DC jack on the side of the unit. Plug the adapter into a 120V AC Household outlet. The Conair® Sound Therapy Relaxation System will also operate without the cord, using four 1.5 volt AA batteries (not included).

FEATURES

- 1) 10 High Quality Digital Recordings
- Summer Night: Relax to the soothing sounds of a gentle summer.
- Rainfall: Ease the mind with the peaceful patter of rain.
- Ocean Waves: Wash away tension with the calming effect of the incoming tide.
- Waterfall: Provide an ideal working background with the refreshing cascade of falling water.
- White Noise: Mask unwanted noise with a background of muffled static.
- Running Stream: Soothe your soul with the serenity of a flowing stream.
- Heartbeat: Calm little ones with the rhythmic beating of a heart.
- Tropical Forest: Travel to a world full of tranquil tropical sounds.
- Songbirds: Wake to the sensation of birds harmoniously singing.
- Thunderstorm: Lull yourself to sleep with the rumbling of a thunderstorm.
- 2) Three-inch speaker for realistic sound quality.
- 3) Optional 60-minute auto shutoff timer.
- 4) ON/Off button.
- 5) Volume control.
- 6) Battery option (four AA batteries not included) with AC adapter included.

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be taken, including the following: Read all instructions before using this appliance.

DANGER—To reduce the risk of electric shock:

- 1) Always unplug this appliance from the electrical outlet immediately after using and before cleaning.
- 2) Do not reach for an appliance that has fallen into water. Unplug immediately.
- 3) Do not use while bathing or in a shower.
- 4) Do not place or store appliance where it can fall or be pulled into a tub or sink. Do not place in or drop into water or other liquid.

WARNING—To reduce the risk of burns, fire, electric shock, or injury to persons:

- 1) An appliance should never be left unattended when plugged in. Unplug from outlet when not in use.
- 2) This appliance is not for use by children or individuals with certain disabilities.
- 3) Do not operate under blanket or pillow. Excessive heating can occur and cause fire, electric shock, or injury to persons.
- 4) Use this appliance only for its intended use as described in this manual.
- 5) Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged, or dropped into water. Return the appliance to a service center for examination and repair.
- 6) Do not carry this appliance by supply cord or use cord as a handle.
- 7) Keep the cord away from heated surfaces.
- 8) Never operate the appliance with the air openings blocked. Keep the air opening free of lint, hair, and other debris.
- 9) Never operate on a soft surface, such as a bed or a couch, where air openings may be blocked.
- 10) Never drop or insert any object into any of the openings.
- 11) To disconnect, turn all controls to the OFF position, then remove plug from outlet.

SAVE THESE INSTRUCTIONS

A.C. ADAPTER

Note: Unit supplied with a UL Listed 6V DC 250mA center positive adapter. For more information, please contact a Conair service center.

- 6) Para utilizar la unión de apagado automático después de 60 minutos, ponga el botón de apagado automático en la posición OFF para que la unidad no se apague automáticamente al cabo de 60 minutos. Para apagar la unidad, oprima el botón de encendido/apagado.
- 7) Ponga el botón de apagado automático en la posición OFF para que la unidad no se apague automáticamente al cabo de una hora. La unidad también se apagará automáticamente la próxima vez que la use si se deja el botón de apagado automático en la posición ON.
- 6) Para utilizar la unión de apagado automático después de 60 minutos, ponga el botón de apagado automático ubicado en el lado de la unidad en la posición ON. La unidad se apagará automáticamente al cabo de una hora. La unidad también se apagará automáticamente la próxima vez que la use si se deja el botón de apagado automático en la posición ON.
- 5) Para ajustar el volumen, gire el disco de control de volumen ubicado en la parte delantera de la unidad.
- 4) Para apagar el aparato, oprima el botón de encendido/apagado otra vez. La unidad memorizará el último sonido utilizado.
- 3) Escoja el sonido deseado entre los 10 sonidos disponibles, oprimiendo el botón correspondiente.
- 2) Oprima el botón de encendido/apagado ON/OFF una vez para encender el aparato. El reproductor de sonidos reproducirá el último sonido usado.
- 1) Conecte el adaptador de C.A. al enchufe de C.D. ubicado en el lado del aparato luego enchúfelo en un tomacorriente de 120V C.A. O instale cuatro baterías de tipo AA (no se incluyen) en el compartimiento para baterías ubicado debajo del aparato. El indicador luminoso se encenderá para indicar que el aparato está conectado.

INSTRUCCIONES DE USO

Notas

- 3) Cierre el compartimiento para baterías.
- 2) Inserta cuatro baterías de 1.5V de tipo AA, respetando los signos de polaridad +/- indicados adentro del compartimento.
- 1) Abra el compartimiento para baterías ubicado debajo del aparato.

reproductor de sonidos naturales



CONAIR®

CARE OF YOUR CONAIR®

SOUND THERAPY RELAXATION SYSTEM

- 1) Before cleaning, unplug the Sound Therapy Relaxation System from the outlet (if using the adapter) or remove the batteries.
- 2) Clean the Sound Therapy Relaxation System only with a soft, slightly damp cloth. Never allow water or any other liquid to come into contact with the sound system.
- 3) DO NOT IMMERSE IN ANY LIQUID TO CLEAN. Never use abrasive cleaners.
- 4) Do not attempt to repair the Sound Therapy Relaxation System.

YOUR CONAIR® SOUND THERAPY RELAXATION SYSTEM

AT A GLANCE

- 10 Soothing Sounds
Heartbeat, Running Stream, Ocean Waves, Tropical Forest, White Noise, Summer Night, Thunderstorm, Rainfall, Waterfall, Rainfall, and Songbirds
- 60-Minute Timer
- DC Jack
- Volume Control
- 3" Speaker
- Battery Compartment

GARANTÍA LIMITADA POR UN AÑO

Conair reparará o reemplazará (a su opción) su aparato sin cargo por un período de 12 meses a partir de la fecha de compra si presenta defectos de mano de obra o en los materiales.

Para obtener servicio técnico bajo esta garantía, mande su aparato al Centro de Servicio más cercano, junto con su recibo de compra y un cheque de \$5,00US para gastos de envío y manejo. Los residentes de California sólo necesitan dar una prueba de compra y deben llamar al **1-800-3-CONAIR** para recibir instrucciones de envío. En ausencia del recibo de compra, el período de garantía será de 12 meses a partir de la fecha de fabricación.

CUALQUIERA GARANTÍA, OBLIGACIÓN O RESPONSABILIDAD IMPLÍCITAS, INCLUYENDO PERO NO LIMITADAS A LA GARANTÍA IMPLÍCITA DE COMERCIABILIDAD Y APTITUD PARA UN PROPÓSITO ESPECÍFICO, ESTARÁN LIMITADAS POR LOS 12 MESES DE LA PRESENTE GARANTÍA ESCRITA. Algunos Estados no permiten limitaciones sobre la duración de una garantía implícita, de modo que las limitaciones mencionadas pueden no regir para usted.

CONAIR NO SERÁ RESPONSABLE EN NINGÚN CASO POR ALGÚN DAÑO ESPECIAL, INCIDENTAL O CONSECUENTE DEBIDO AL INCUMPLIMIENTO DE ESTA O DE CUALQUIER OTRA GARANTÍA, EXPRESA O IMPLÍCITA. Algunos Estados no permiten la exclusión o limitación de daños especiales, incidentales o consecuentes, de modo que las limitaciones mencionadas pueden no regir para usted.

Esta garantía le otorga derechos legales específicos y usted puede tener otros derechos que varían de un Estado a otro.

Centros de Servicio:

Conair Corporation
Service Department
150 Milford Road
East Windsor, NJ 08520

Conair Corporation
Service Department
7475 North Glen Harbor Blvd.
Glendale, AZ 85307

Visítenos en la Web en www.conair.com
©2007 Conair Corporation
East Windsor, NJ 08520, Glendale, AZ 85307

IB-6154A
SU1W
07PS078

LIMITED ONE YEAR WARRANTY

Conair will (at our option) repair or replace your appliance free of charge for 12 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service center nearest you, together with your sales slip and \$5.00 for postage and handling. California residents need only provide proof of purchase and should call 1-800-3-CONAIR for shipping instructions. In the absence of a purchase receipt, the warranty period will be 12 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 12 MONTH DURATION OF THIS WARRANTY. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. Some states do not allow the exclusion or limitation of special, incidental or consequential damages, so the above limitation may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

For service, please bring or send defective unit with sales slip to the nearest service center listed below.

Service Centers:
Conair Corporation
Service Department
150 Milford Road
East Windsor, NJ 08520
Visit us on the web at: www.conair.com
©2007 Conair Corporation
East Windsor, NJ 08520, Glendale, AZ 85307

IB-6154A
SU1W
07PS078

FAMILIARÍCESE CON SU REPRODUCTOR DE SONIDOS NATURALES DE CONAIR®



INSTRUCCIONES DE MANTENIMIENTO

- 1) Desenchufe el aparato y/o remueva las baterías antes de limpiarlo.
- 2) Limpie el cuerpo del aparato con un paño suave ligeramente humedecido. No lo moje.
- 3) NO SUMERJA EL APARATO EN AGUA U OTRO LÍQUIDO. Nunca utilice materiales o limpiadores abrasivos.
- 4) Si ocurriera un problema, no intente reparar la unidad. Regrésela a un centro de servicio autorizado.

CONAIR®



sound therapy

INSTRUCTION BOOKLET FOR MODEL SU1W
For your safety and continued enjoyment of this product, always read the instruction book carefully before using.